

# **Table of contents**

Safety 4 General information 4	Switching off the appliance
Intended use	Additional functions
Safe installation	Refrigerator compartment
Preventing material damage 10	Chill zones in the refrigerator compartment
Environmental protection and saving energy10	"OK" sticker17
Disposing of packaging	Freezer compartment
Installation and connection 11	Tips for buying frozen food 18
Scope of delivery	Tips for storing food in the freezer compartment
tion 12	−18 °C19
Preparing the appliance for the first time12	Defrosting methods for frozen food20
Connecting the appliance to the electricity supply12	Defrosting
Familiarising yourself with	Defrosting in the refrigerator compartment20
your appliance	Defrosting in the freezer compartment
Controls14	Cleaning and servicing 21
Features         14           Shelf         15           Pull-out container         15	Preparing the appliance for cleaning
Fruit and vegetable container with cover	Cleaning the condensation channel and drainage hole
Basic operation16Switching on the appliance16Operating tips16	Troubleshooting24Malfunctions24Temperature problem26

Noise Odours	
Storage and disposal  Switching off the appliance  Disposing of old appliance	27
Customer Service Product number (E-Nr.) and production number (FD)	
Technical data	28



# **△** Safety

Please read the safety information to ensure that you use the appliance safely.

#### General information

You can find general information for this instruction manual here.

- Read this instruction manual carefully. Only this will ensure you use the appliance safely and efficiently.
- This manual is intended for the user of the appliance.
- Follow the safety instructions and warnings.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Check the appliance after unpacking it. Do not connect the appliance if it has been damaged in transit.

#### Intended use

Read the information on intended use to ensure that you use the appliance correctly and safely.

Only use this appliance:

- As specified in this instruction manual.
- For chilling and freezing food and making ice.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 2000 m above sea level.

## Restriction on user group

Avoid risks to children and vulnerable persons.

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

Children above the age of three years old and younger than eight years old may load and unload the the fridge-freezer.

# Safe transport

Follow these safety instructions when transporting the appliance.

# **⚠** WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

#### Safe installation

Follow these safety instructions when installing the appliance.

# 

- Improper installation is dangerous.
  - ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
  - Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
  - ► The protective conductor system of the domestic electrical installation must be properly installed.
  - ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
  - ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
  - ► When installing the appliance, check that the power cable is not trapped or damaged.
- If the insulation of the power cord is damaged, this is dangerous.
  - Never let the power cord come into contact with heat sources.

#### en Safety

- Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

# **⚠** WARNING – Risk of explosion!

If the appliance's ventilation openings are sealed, a leak in the refrigeration circuit may result in a flammable mixture of gas and air.

► Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

## MARNING – Risk of fire!

- It is dangerous to use an extended power cord and non-approved adapters.
  - ▶ Do not use extension cables or multiple socket strips.
  - ▶ If the power cord is too short, contact Customer Service.
  - ▶ Only use adapters approved by the manufacturer.
- Portable multiple socket strips or portable power supply units may overheat and cause a fire.
  - ▶ Do not place portable multiple socket strips or power supply units on the back of the appliance.

## Safe use

Follow these safety instructions when using the appliance.

# **⚠** WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ► Do not use steam- or high-pressure cleaners to clean the appliance.

# ⚠ WARNING – Risk of suffocation!

- Children may put packaging material over their heads or wrap themselves up in it and suffocate.
  - ► Keep packaging material away from children.
  - ▶ Do not let children play with packaging material.

- Children may breathe in or swallow small parts, causing them to suffocate.
  - ► Keep small parts away from children.
  - ▶ Do not let children play with small parts.

# ⚠ WARNING – Risk of explosion!

- Mechanical devices or other devices may damage the refrigeration circuit; flammable refrigerant may escape and explode.
  - ► To accelerate the defrosting process, do not use any other mechanical devices or devices other than those recommended by the manufacturer.
- Products which contain flammable propellants and explosive substances may explode, e.g. spray cans.
  - ▶ Do not store products which contain flammable propellants (e.g. spray cans) or explosive substances in the appliance.

## ⚠ WARNING – Risk of fire!

- Electrical devices within the appliance may cause a fire, e.g. heaters or electric ice makers.
  - ▶ Do not operate electrical devices within the appliance.
- The vapours from flammable liquids may catch fire (explosion).
  - ► Store high-percentage alcohol tightly closed and standing up.

# ⚠ WARNING – Risk of injury!

- Containers that contain carbonated drinks may burst.
  - ▶ Do not store containers that contain carbonated drinks in the freezer compartment.
- Injury to the eyes caused by escaping flammable refrigerant and hazardous gases.
  - ▶ Do not damage the tubes of the refrigerant circuit or the insulation.

# **⚠** WARNING – Risk of cold burns!

Contact with frozen food and cold surfaces may cause burns by refrigeration.

- ► Never put frozen food straight from the freezer compartment into your mouth.
- ► Avoid prolonged contact of skin with frozen food, ice and the tubes in the freezer compartment.

# **△** CAUTION – Risk of harm to health!

- To prevent food from being contaminated, you must observe the following instructions.
  - ▶ If the door is open for an extended period of time, this may lead to a considerable temperature increase in the compartments of the appliance.
  - ► Regularly clean the surfaces that may come into contact with food and accessible drain systems.
  - ► Store raw meat and fish in suitable containers in the refrigerator so that they do not touch or drip on other food.
  - ▶ If the fridge/freezer is empty for an extended period of time, switch off the appliance, defrost it, clean it and leave the door open to prevent the formation of mould.
- If acidic food comes into contact with aluminium in the appliance, aluminium foil ions may pass into the food.
  - ▶ Do not consume soiled food.

# **Damaged appliance**

Follow the safety instructions if your appliance is damaged.

# 

- If the appliance or the power cord is damaged, this is dangerous.
  - ► Never operate a damaged appliance.
  - ► Never operate an appliance with a cracked or fractured surface.
  - ► "Call Customer Service." → Page 27
  - ► Repairs to the appliance should only be carried out by trained specialist staff.

- Incorrect repairs are dangerous.
  - ► Repairs to the appliance should only be carried out by trained specialist staff.
  - ▶ Only use genuine spare parts when repairing the appliance.
  - ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

# **⚠** WARNING – Risk of fire!



If the tubes are damaged, flammable refrigerant and harmful gases may escape and ignite.

- ► Keep naked flames and ignition sources away from the appliance.
- ▶ Ventilate the room.
- Switch off the appliance." → Page 16
- ► Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- ► "Call after-sales service." → Page 27

# Preventing material damage

Follow these instructions to prevent material damage to your appliance, accessories or other objects in your kitchen.

#### **ATTENTION!**

- Using the base, runners or appliance doors as a seat surface or climbing surface may damage the appliance.
  - Do not stand or support yourself on the base, runners or doors.
- Contamination with oil or fat may cause plastic parts and door seals to become porous.
  - Keep plastic parts and door seals free of oil and grease.
- Metal or metal-style parts in the appliance may contain aluminium. Aluminium reacts when it comes into contact with acidic foods.
  - Do not store unpackaged food in the appliance.

# **Environmental protection** and saving energy

Help protect the environment by using your appliance in a way that conserves resources and by disposing of reusable materials properly.

# Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

Information about current disposal methods are available from your specialist dealer or local authority.

# Saving energy

If you follow these instructions, your appliance will use less power.

#### Selecting the installation location

Follow these instructions when installing your appliance.

- Keep the appliance out of direct sunlight.
- Install the appliance as far away as possible from heating elements, cookers and other heat sources:
  - Maintain a 30 mm clearance to electric or gas cookers.
  - Maintain a 30 cm clearance to oil or solid-fuel cookers
- + The appliance needs to cool less frequently at low ambient temperatures.
- Do not cover or block ventilation openings.
- + The air on the back wall of the appliance can escape more easily and the appliance does not warm up so intensely.

The appliance must cool less frequently.

## Saving energy during use

Follow these instructions when using your appliance.

Note: The arrangement of the fittings does not affect the energy consumption of the appliance.

- Do not cover or block ventilation openings.
- + The air on the back wall of the appliance can escape more easily and the appliance does not warm up so intensely.
- Open the appliance door only briefly.
- Transport purchased food in a cool bag and place in the appliance quickly.
- Allow warm food and drinks to cool down before placing them in the appliance.
- Thaw frozen food in the refrigerator compartment to utilise the low temperature of the food.
- + The air in the appliance does not warm up so intenselv. The appliance must cool less frequently.
- Always leave some space between the food and to the back panel.
- Pack the food airtight.
- + The air can circulate and the air humidity remains constant.
- Defrost the freezer compartment regularly.
- + A frost-free freezer compartment is power-saving and cools the frozen food optimally.
- Only open the freezer compartment door briefly and then carefully close it.
- + A closed freezer compartment door protects the freezer compartment against severe icing.

# Installation and connection

# Scope of delivery

After unpacking all parts, check for any transport damage and for completeness of delivery.

If you have any complaints, contact your dealer or our "after-sales service" → Page 27.

The delivery consists of the following:

- Built-under appliance
- Equipment and accessories<sup>1</sup>
- Installation material
- Installation instructions
- User manual
- Customer service booklet
- Warranty enclosure<sup>2</sup>
- Energy label
- Information on energy consumption and noises

# Installing and connecting the appliance

**Requirement:** "The scope of delivery of the appliance is checked."

- → Page 11
- 1. "Observe the criteria for the appliance's installation location." → Page 12
- 2. Install the appliance according to the enclosed installation instructions.
- **3.** "Prepare the appliance for first use." → Page 12
- 4. "Electrically connect the appliance." → Page 12

Depending on the appliance specifications

Not in all countries

## Criteria for the installation location

Follow these instructions when installing your appliance.

# ⚠ WARNING Risk of explosion!

If the appliance is in a space that is too small, a leak in the refrigeration circuit may result in a flammable mixture of gas and air.

Only install the appliance in a space with a volume of at least 1 m<sup>3</sup> per 8 g refrigerant. The volume of refrigerant is indicated on the rating plate. → "Appliance", Fig. 1 / 5 , Page 14

The weight of the appliance ex works may be up to 35 kg depending on the model.

The subfloor must be of sufficient stability to bear the weight of the appliance.

### Permitted room temperature

The permitted room temperature depends on the appliance's climate class.

The climate class can be found on the rating plate.  $\rightarrow$  "Appliance", Fig.

1 / 5 , Page 14

Climate class	Permitted room temperature
SN	10 °C to 32 °C
N	16 °C to 32 °C
ST	16 °C to 38 °C
T	16 °C to 43 °C

The appliance is fully functional within the permitted room temperature. If an appliance with climate class SN is operated at colder room temperatures, the appliance will not be damaged up to a room temperature of 5 °C.

#### **Built-under**

Attachment under certain worktops, e.g. stone, glass or stainless steel, is frequently not possible. You can order accessories from customer service for installation on the side walls. → "Customer Service", Page 27

## Preparing the appliance for the first time

- 1. Remove the informative material.
- 2. Remove the protective foil and transit bolts, e.g. remove the adhesive strips and carton.
- 3. "Clean the appliance for the first time." → Page 21

# Connecting the appliance to the electricity supply

1. Insert the mains plug of the appliance's power cable in a socket nearby.

The connection data of the appliance can be found on the rating plate. → "Appliance", Fig. 1/5, Page 14


- 2. Check the mains plug is inserted properly.
- ▼ The appliance is now ready for use.

# Familiarising yourself with your appliance

Familiarise yourself with the parts of your appliance.

# **Appliance**

You can find an overview of the parts of your appliance here.



1	
н	



Refrigerator compartment

1	Light switch	
2	Controls	

#### en Features

3	Main switch
4	"Pull-out container" → Page 15
5	Rating plate
6	Fruit and vegetable container


7	Ventilation grille
R	Door storage compartment for large

8 Door storage compartment for large bottles

**Note:** Deviations between your appliance and the diagrams may differ with regard to their features and size.

### **Controls**

The controls are used to configure all functions of your appliance and to obtain information about the operating status.



2

1	The main switch turns the appliance
	on or off.

- Super switches Super freezing on or off.
- Displays the set temperature for the refrigerator compartment in °C.
- C sets the temperature of the refrigerator compartment.

# **Features**

Here you can see an overview of the features of your appliance and their use.

The features of your appliance depend on the model.

#### Shelf

To vary the shelf as required, you can remove the shelf and re-insert it elsewhere.

→ "Removing the shelf", Page 22

#### **Pull-out container**

Do not store animal-based food in the pull-out container. "You can take out the pull-out container for loading and unloading." → Page 22

## Fruit and vegetable container with cover

Store fresh fruit and vegetables in the fruit and vegetable container. "Remove the fruit and vegetable container loading and unloading."

→ Page 23

Condensation may form in the fruit and vegetable container depending on the food and quantity stored. Remove the condensation with a dry cloth.

To ensure that the quality and aroma are retained, store fruit and vegetables that are sensitive to cold outside of the appliance at temperatures of approx. 8 °C to 12 °C.

# to cold Vegetables that are sensitive to cold Gherkins

Fruit that is sensitive

- Pineapples
- Bananas
- Mangoes
- Papayas
- Citrus fruits
- Aubergines
- Courgettes
- Peppers
- Tomatoes
- Potatoes

#### Door racks

To adjust the door racks as required, you can remove the door rack and re-insert elsewhere.

→ "Removing door racks", Page 22

#### Accessories

Only use original accessories. These have been made especially for your appliance. Here you can find an overview of your appliance's accessories and how to use them.


The accessories for your appliance depend on the model.

#### Egg tray

Store eggs safely on the egg tray.

#### **Bottle holder**

The bottle holder prevents bottles from falling over when the appliance door is opened and closed.



### Ice cube tray

Use the ice cube tray to make ice cubes.

# Making ice cubes

1. Fill the ice cube tray with water up to 3/4 and place in the freezer compartment.

If the ice cube tray is stuck to the freezer compartment, loosen it with a blunt implement only (e.g. spoon handle).

To loosen the ice cubes, twist the ice cube tray slightly or hold it briefly under flowing water.

# **Basic operation**

You can find out everything you need to know about operating your appliance here.

# Switching on the appliance

- Switch on the appliance at the main switch. → "Appliance", Fig.
   1/3. Page 14
- ▼ The appliance begins to cool.
- The temperature display flashes until the appliance has reached the set temperature.
- 2. "Set the required temperature."

  → Page 16

# **Operating tips**

- Once you have switched on the appliance, the set temperature is only reached after several hours.
   Do not put any food in the appliance until the temperature has been reached.
- When you close the door, a vacuum may be created. The door is then difficult to open again. Wait a moment until the vacuum is offset.

# Switching off the appliance

- Switch off the appliance at the main switch. → "Appliance", Fig.
   1/3. Page 14
- ▼ The appliance stops cooling.

# Setting the temperature

After you have switched on the appliance, you can set the temperature.

# Setting the refrigerator compartment temperature

 Press °C repeatedly until the temperature display shows the required temperature.

The recommended temperature in the refrigerator compartment is 4 °C.

→ ""OK" sticker", Page 17

# Setting the freezer compartment temperature

In order to set the freezer compartment temperature, "change the refrigerator compartment temperature" → Page 16.

The refrigerator compartment temperature influences freezer compartment temperature. Refrigerator compartment temperatures that are set to warm generate warmer freezer compartment temperatures.

## **Additional functions**

Find out which additional functions which can be used for your appliance.

# Super freezing

Super freezing cools the freezer compartment as cold as possible. This freezes food quickly right through to the centre.

Switch on Super freezing four to six hours before placing food weighing 2 kg or more into the freezer compartment.

In order to utilise the freezer capacity, use Super freezing.

→ "Prerequisites for freezing capacity", Page 18

**Note:** When Super freezing is switched on, increased noise may occur.

#### Switching on Super freezing

- Press super
- super lights up.

Note: After approx. 48 hours, the appliance switches to normal operation.

### Switching off Super freezing

Press super

# Refrigerator compartment

You can keep meat, sausage, fish, dairy products, eggs, prepared meals and pastries in the refrigerator compartment.

You can set the temperature in the refrigerator compartment from 2 °C to 8°C.

The recommended temperature in the refrigerator compartment is 4 °C. → ""OK" sticker". Page 17

The refrigerator compartment can also be used to store highly perishable foods in the short to medium term. The lower the selected temperature, the longer the food remains fresh

# Tips for storing food in the refrigerator compartment

Follow the tips if you store food in your refrigerator compartment.

To ensure that the freshness and quality of the food is retained for longer, only store fresh and unspoiled food.

- In the case of ready-made products and bottled goods, do not exceed the best-before date or use-by date specified by the manufacturer.
- To retain aroma, colour and freshness or to prevent taste transfer and discolouration of the plastic parts, store food well wrapped or covered.
- Leave warm food and beverages to cool down before placing them in the refrigerator compartment.

# Chill zones in the refrigerator compartment

The air circulation in the refrigerator compartment creates different chill zones.

#### Coldest zone

The coldest zone is in the pull-out container.

#### Warmest zone

The warmest zone is at the very top of the door.

**Tip:** Store food that does not spoil easily in the warmest zone, e.g. hard cheese and butter. Cheese can then continue to release its aroma and the butter will still be easy to spread.

### "OK" sticker

The "OK" sticker lets you check whether the refrigerator compartment reaches the safe temperature ranges of +4 °C or colder recommended for food.

The "OK" sticker is not included with all models.

If the sticker does not indicate "OK", gradually reduce the temperature. → "Setting the refrigerator compartment temperature", Page 16

Once the appliance is switched on, it may take up to 12 hours until the set temperature is reached.



Correct setting

# Freezer compartment

You can store frozen food, freeze food and make ice cubes in the freezer compartment.

The temperature in the freezer compartment depends on the temperature in the refrigerator compartment. Long-term storage of food should be at –18 °C or lower.

The freezer compartment can be used to store perishable food long-term. The low temperatures slow down or stop the spoilage.

The time between putting fresh food in the freezer compartment and it freezing solid depends on various factors:

- Set temperature
- Food (size and type)
- Quantity and type of storage
- Quantity and type of food already stored

## Freezer compartment door

To ensure that the frozen food that is stored does not thaw and the freezer compartment is not covered in too much ice, always close the freezer compartment door.

**Note:** When you close the freezer compartment door, you can hear it engaging.

# Freezing capacity

The maximum freezing capacity indicates the quantity of food that can be frozen right through to the centre within a specific period of time. Information on the maximum freezing capacity can be found on the rating plate. → "Appliance", Fig. 1/5, Page 14

#### Prerequisites for freezing capacity

- When placing fresh food in the appliance, switch on Super freezing.
   → "Switching on Super freezing", Page 17
- Place the food as close as possible to the back wall of the freezer compartment. This is where the food freezes most quickly.

# Tips for buying frozen food

Follow the tips when you are buying frozen food.

- Check the packaging is not damaged.
- Check the best-before date.
- The temperature in the supermarket freezer must be -18 °C or lower.
- Do not interrupt the deep-freeze chain. If possible, transport frozen food in a cool bag and quickly place it in the freezer compartment.

# Tips for storing food in the freezer compartment

Follow the tips if you are storing food in the freezer compartment.

- Spread out the food over a wide area in the freezer compartment.
- Do not bring food which is to be frozen into contact with frozen food.

If necessary, redistribute frozen food in the freezer compartment.

# Tips for freezing fresh food

Follow the tips when you freeze fresh food.

- Freeze fresh and undamaged food only.
- Cooked food is more suitable than food that can be eaten raw.
- In order to retain the nutritional value, flavour and colour, vou should prepare certain food for freezing.
  - Vegetables: Wash, chop up, blanch.
  - Fruit: Wash, pit and perhaps peel, possibly add sugar or ascorbic acid solution.

Additional information on how to do this can be found in the relevant literature.

#### Food suitable for freezing

- Baked goods
- Fish and seafood
- Meat
- Poultry and game
- Vegetables, fruit and herbs
- Eggs without shells
- Dairy products, e.g. cheese, butter and quark
- Ready meals and leftovers, e.g. soups, stews, cooked meat and fish, potato dishes, bakes and desserts

### Food that is unsuitable for freezing

- Types of vegetables that are usually eaten raw, e.g. lettuce or radishes
- Unpeeled or hard-boiled eggs
- Grapes
- Whole apples, pears and peaches
- Yoghurt, soured milk, sour cream, crème fraîche and mayonnaise

#### Packing frozen food

If you select suitable packaging material and the correct type of packaging, you can determine the product quality and prevent freezer burn.

- 1. Place the food in the packaging. Suitable packaging:
  - Plastic film made of polyethyl-
  - Tubular film made of polyethyl-
  - Freezer bags made from polyethylene
  - Freezer containers Unsuitable packaging:
  - Wrapping paper
  - Greaseproof paper
  - Cellophane
  - Aluminium foil
  - Rubbish bags and used shopping bags
- 2. Squeeze out the air.
- 3. Pack food airtight to prevent it from losing flavour and drying out. Suitable seals:
  - Rubber bands
  - Plastic clips
  - Cold-resistant adhesive tape
- 4. Label the packaging with the contents and the date of freezing.

## Shelf life of frozen food at -18 °C

Observe the storage times when you freeze food.

Food	Storage time
Fish, sausages, prepared meals and baked goods	Up to 6 months
Poultry, meat	Up to 8 months
Vegetables, fruit	Up to 12 months

# Defrosting methods for frozen food

To retain the best-possible product quality, the defrosting method must be adjusted to the food and application.

# ⚠ CAUTION Risk of harm to health!

During the thawing process, bacteria may multiply and spoil the frozen food.

- Do not refreeze food after it has been defrosted or started to defrost.
- Refreeze food only after cooking.
- These items should no longer be stored for the maximum storage period.

Defrosting method	Food
Refrigerator compartment	Animal-based food such as fish, meat, cheese, quark
Room temperature	Bread
Microwave	Food for immediate consumption or immediate preparation
Oven or cooker	Food for immediate consumption or immediate preparation

# **Defrosting**

Observe the information when you want to defrost your appliance.

# Defrosting in the refrigerator compartment

When the appliance is operating, condensation droplets or frost form on the rear panel of the refrigerator

compartment due to functional reasons. The back panel in the refrigerator compartment defrosts automatically.

Condensation runs through the condensation channel into the drainage hole to the evaporation pan and does not have to be wiped away.

To ensure that the condensation can drain and odours do not form, observe the following information:

→ "Cleaning the condensation channel and drainage hole", Page 22.

# Defrosting in the freezer compartment

As the frozen food must not start thawing, the freezer compartment does not defrost automatically. A layer of hoarfrost in the freezer compartment impairs refrigeration of the frozen food and increases power consumption.

### Defrosting the freezer compartment

Regularly defrost the freezer compartment.

- Switch on Super freezing approx. four hours before defrosting.
   → "Switching on Super freezing", Page 17
  - This means that the food reaches very low temperatures and it can be stored for longer at room temperature.
- 2 Remove the frozen food and temporarily place it in a cool location. Place ice packs (if available) on the frozen food.
- "Switch off the appliance."
   → Page 16
- **4.** Disconnect the appliance from the power supply.
  - Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

- 5. To accelerate the defrosting process, place a pan of hot water on a trivet in the freezer compartment.
- **6.** Wipe up the condensation water with a soft cloth or sponge.
- 7. Rub the freezer compartment dry with a soft, dry cloth.
- 8. Electrically connect the appliance.
- 9. "Switch on the appliance." → Page 16
- 10. "Put the frozen food in the appliance." → Page 18

# Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully. Customer Service must clean inaccessible points. Cleaning by customer service can give rise to costs.

# Preparing the appliance for cleaning

Find out how to prepare your appliance for cleaning.

- 1. "Switch off the appliance." → Page 16
- 2. Disconnect the appliance from the power supply.
  - Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. Take out all of the food and store it in a cool place.
  - Place ice packs (if available) onto the food.
- 4. If there is a layer of hoarfrost, allow this to defrost.
- 5. "Remove all fittings from the appliance." → Page 22

# Cleaning the appliance

Clean the appliance as specified to ensure that it is not damaged by incorrect cleaning or unsuitable cleaning products.

# ⚠ WARNING Risk of electric shock!

- An ingress of moisture can cause an electric shock.
  - Do not use steam- or high-pressure cleaners to clean the appli-
- Liquid in the lighting can be dangerous.
  - The rinsing water must not run into the light.

#### ATTENTION!


- Unsuitable cleaning products may damage the surfaces of the appliance.
  - Do not use hard scouring pads or cleaning sponges.
  - ▶ Do not use harsh or abrasive detergents.
  - ▶ Do not use cleaning products with a high alcohol content.
- If you clean fittings and accessories in the dishwasher, this may cause them to become deformed or discolour.
  - Never clean fittings and accessorv in the dishwasher.
- 1. "Prepare the appliance for cleaning." → Page 21
- 2. Clean the appliance, the fittings and the door seals with a dish cloth, lukewarm water and a little pH-neutral washing-up liquid.
- **3.** Dry thoroughly with a soft, dry cloth.
- 4. Insert the fittings.
- **5.** Electrically connect the appliance.
- 6. "Switch on the appliance."
  - → Page 16

**7.** Putting the food into the appliance.

# Cleaning the condensation channel and drainage hole


Regularly clean the condensation channel and drainage hole to ensure that the condensation can drain.

- Remove the pull-out container.
   → "Removing pull-out containers",
   Page 22
- 2. Carefully clean the condensation channel and the drainage hole, e.g. using a moistened cotton bud.



# Cleaning the ventilation grille

- **1.** Remove the ventilation grille for cleaning.
  - To do this, depress the clips in the ventilation openings and simultaneously remove the ventilation grille forwards.




- Clean the ventilation grille with lukewarm soapy water and a dish cloth.
- **3.** Let the ventilation grille dry completely and insert it.

# Removing the fittings

If you want to clean the fittings thoroughly, remove these from your appliance.


## Removing the shelf

► Lift the shelf, pull it out, lower it and swing it out to the side.




# Removing door racks

Lift the door rack upwards and remove it.




### Removing pull-out containers

Lift the pull-out container and remove it.



### Remove the fruit and vegetable container with the lid

► Fold up the lid of the fruit and vegetable container ① and remove the fruit and vegetable container with lid towards the front 2.





# **Troubleshooting**

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

#### ⚠ WARNING

#### Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

#### **Malfunctions**

Fault	Cause	troubleshooting
The appliance is not working.  No displays light up.	The mains plug has not been inserted properly.	Check whether the mains plug for the power cord is fully inserted into the socket.
1 7 0 1	Fuse has been tripped.	► Check the fuses.
	The power has failed.	<ol> <li>Check whether the power is on.</li> <li>Place ice packs (if available) on the frozen food.</li> </ol>

blocked.

## en Troubleshooting

# **Temperature problem**

Fault	Cause	troubleshooting
The temperature differs greatly from the setting.	Different causes are possible.	<ol> <li>"Switch off the appliance."         → Page 16</li> </ol>
		2 "Switch the appliance back on after five minutes." → Page 16
		<ul> <li>If the temperature is too warm, check the temperature again after a couple of hours.</li> <li>If the temperature is too cold, check the temperature again on the following day.</li> </ul>

# Noise

Fault	Cause	troubleshooting
Appliance has a humming sound.	Not a fault. A motor is running, e.g. refrigerating unit, fan.	No action required.
The appliance bubbles, buzzes or gargles.	Not a fault. Refrigerant flows through the pipes.	No action required.
The appliance clicks.	Not a fault. Motor, switches or solenoid valves are switching on or off.	No action required.
The appliance makes noises.	Fittings wobble or stick.	► Check the removable fittings and, if required, replace these.
	Bottles or containers are touching.	Move the bottles or containers away from each other.
	Super freezing is switched on.	No action required.

# **Odours**

Fault	Cause	troubleshooting
The appliance has an unpleasant smell.	Different causes are possible.	<ol> <li>"Prepare the appliance for cleaning." → Page 21</li> <li>"Clean the appliance." → Page 21</li> <li>Clean all food packaging.</li> <li>To prevent odours from forming, store strong smelling food in airtight containers.</li> <li>After 24 hours, check whether odours are still forming.</li> </ol>

# Storage and disposal

You can find out here how to prepare your appliance for storage. You will also find out how to dispose of old appliances.

# Switching off the appliance

- 1. "Switch off the appliance." → Page 16
- 2. Disconnect the appliance from the power supply.
  - Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. "Defrost the appliance." → Page 20
- 4. "Clean the appliance." → Page 21
- 5. To ensure the ventilation inside the appliance, leave the appliance open.

# Disposing of old appliance

Valuable raw materials can be reused by recycling.

# ⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Leave shelves and containers inside the appliance to prevent children from climbing in.
- Keep children away from the redundant appliance.

# ⚠ WARNING Risk of fire!

If the tubes are damaged, flammable refrigerant and harmful gases may escape and ignite.

▶ Do not damage the tubes of the refrigerant circuit or the insulation.

▶ Dispose of the appliance in an environmentally friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

## **Customer Service**

If you have any queries, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service. You can solve many problems yourself by consulting the information on troubleshooting in these instructions or on our website. If this is not the case, contact our after-sales service. We will always find an appropriate solution and try to avoid unnecessary visits being made by a Customer Service technician.

With any warranty claims, we will make sure that your appliance is repaired by trained after-sales technicians using genuine spare parts, including after the manufacturer's warranty has expired.

For safety reasons repairs to the appliance should only be carried out by trained specialist staff. The warranty claim becomes void if repairs or interventions have been carried out by persons not authorised by us for that purpose or if our appliances have been fitted with spare, supplementary or accessory parts that were not genuine parts and then resulted in a defect.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

**Note:** Under the terms of the manufacturer's warranty applicable to the location, the use of Customer Service is free of charge. The minimum duration of the warranty (manufacturer's warranty for private consumers) in the European Economic Area is 2 years according to the terms of warranty applicable to the location. The terms of warranty do not affect other rights or claims held by yourself under local legislation.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

# Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate.

→ "Appliance", Fig. 1/5, Page 14 Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

## Technical data

Refrigerant, cubic capacity and further technical specifications can be found on the rating plate.

→ "Appliance", Fig. 1/5, Page 14
More information about your model can be found online at https://energylabel.bsh-group.com¹. This web address is linked to the official EU EPREL product database. At the time of printing its web address had not yet been published. Please then follow the instructions on searching for models. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively you can also find the model identifier in the first line of the EU energy label.


<sup>&</sup>lt;sup>1</sup> Only applies to countries in the European Economic Area













REGISTER YOUR PRODUCT ONLINE NEFF-HOME.COM

Constructa-Neff Vertriebs-GmbH Carl-Wery-Straße 34 81739 München GERMANY



9001482502

en

200609